



COOL-WHIP
CAMPERS

Coolwhip Campers

Unit 2

Gallows park

Millbrook

PL11 3AX



07399 637083



Info@coolwhipcampers.com

Finger bed instructions

1. Download the VW T5/6 furniture kit manual from <https://coolwhipcampers.com/thank-you>. Here you will find tips relevant info on how to correctly T-trim, hang doors and fit catches
2. T trim where required
3. Fit hinges and catches
4. Screw piece 5A to piece 5 using 25mm screw and the pilot holes provided
5. Fit the framework using the diagram with pieces 1-5 using 16mm screws and chock blocks
6. Fit piece 6 securing with 16mm screws and chock blocks
7. Attach the 4 x concealed hinges to piece 8
8. Attach piece 8 to piece 1 via the hinge plates and pilot holes; the hinges are adjustable
9. Screw piece 9 to the underside end of the fingers of piece 8A, use the chock blocks and pilot holes, fit at 90 degrees to each other. Piece 9 will act as a stopper when the bed is pulled out
10. Finally, fit piece 8A to piece, then lift the hinged piece 8 up to allow the install

